

Print Advice

- Print the cheat sheet on a laser printer double sided in landscape. Size -> [x] double sided -> Use [x] mirrored on the short edge
- The height of the cut out should be 62mm maximum, better 1 mm less. If yours is too big try "fit" in your printer settings or play with the scaling factor, e.g. 96%
- Cut it out, fold it in half down to 31mm height, or lower
- Then fold in zig zag to 30mm width. The zig zag folding is pyramid shaped and not straight. If the folds are on top of each other the stack gets probably too high.
- Now it should be small enough to be stored it in the tail cap of the BLF Q8.

Links Q8 lamp on BLF: <http://budgetlightforum.com/node/45915> or <http://bit.ly/blfq8>
Produced by Thorfire: <http://thorfiredirect.com> Videos: configuration <http://bit.ly/narsil-vid3> @8.5min
A Lithium Ion Safety 101 on BLF: <http://bit.ly/liionsafety>
Narsil software in the Q8 thread on BLF: <http://bit.ly/narsilinfo> Videos about UI: <http://bit.ly/narsil-vid1>
Narsil Homepage with Narsil Manual (PDF) and Advanced Notes (PDF) : <http://bit.ly/NarsilQ8>
Narsil Cheat Sheet (PDF) to print by yourself: <http://bit.ly/narsil-cs>

Navigation has "Lock in Mode". **Explanation:** Navigation works only in Modes and Strobe, not in Ramping.
After 1.2sec after setting the brightness you can not increase the brightness with a single click, because it turns it off.
But you can first decrease the brightness by a click&hold and then increase by a single click.
A click&hold in MODES or STROBES wrap from 1st mode to last.

Ramping Explained A click&hold increases the brightness. If you miss your desired brightness / overshoot, a second click&hold reduces the brightness. So it toggles direction with each click&hold. (Timeout for this is 1.2sec)
If your lamp is off, a click&hold starts first moonlight, pauses shortly and then ramps up.
To indicate the maximum or minimum brightness level the lamp flickers when it reaches this limits.
When you release the switch it tells what channel you use: 1 blink of the button = 7135 , 2 blinks = FET+7135
To turn the indicator light temporarily off, turn the light quickly off, while flashing the channel. Works at any level in ON. From OFF a slowish double press does the trick.

If You Want to switch from a low brightness level to FULL and back again to the lower level:
2x for FULL brightness, then 1x for OFF and 1x for last memorized brightness. (Works only in Ramping)

Concept and Design by J. Hollmann

Safety Measures in Narsil

The use of 4 batteries is recommended.
Indication it is ready: 2x blinks after power is applied

In case of a jammed button: Shut off after 20sec

Electronic Lock Out in Ramping:

Lock out turn ON or OFF 4x click
(4x short blinks)

Electronic Lock Out in Modes:

Lock out turn ON or OFF 2x click + click&hold
(4x short blinks)

Overheat protection: Output is lowered at 55°C

Low Voltage Protection (LVP)

Output decreasing from (fuel saver) 3.0V on.

Main LED: 3x blinks as indication.

Indicator LED: every 8 sec two blinks as indication.

Shut off at 2.8V

Main LED: 8x blinks as indication and shut off


Indicator LED: every 8 sec two blinks (for 6 min)

You should at least **remove the cells** or **do a mechanical lockout** to prevent any more drainage! Otherwise your batteries can be damaged.

This lamp belongs to:

If found please:
Tel.

Email



An alternative idea to store the cheat sheet in the BLF Q8:

I printed a copy of the cheat sheet a little larger (75 mm high after cutting) and rolled it up – it now fits perfectly between the four cells. I can read this larger version. (Lazy-R-Us)
Or you put the folded cheat sheet in the tailcap and the notes section between the batteries.

